

SPY  
CODE

# BREAK FREE™

## Troubleshooting :

If you are unable to reach the exit of the maze and want to get out, turn the maze cover counterclockwise and pull the key out together with the maze. Use the backside of the key to push in the emergency release button on the backside of the handcuff (B). The handcuff will immediately open up.

