

SPY
CODE

Safe breaker™

SCAN → SPY SOLVE

AGE
6+

2-4

15'

YUZU

How to set up :

Remove the battery cover on the bottom of the vault and insert three AA batteries (cross head screwdriver required to remove battery cover). Before you start playing put the three diamond stickers and one alarm bell stickers on any four of the golden coins.



| D LR20 | C LR14 | AA LR06 | AAA LR03 |
|-----------|-----------|------------|-------------|
| 1.5V | 1.5V | 1.5V | 1.5V |
| | | 3x | |

Batteries not included.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

CAN ICES - 3 (B) / NMB - 3 (B)

Requires 3 AA/LR6 Batteries. (Batteries Not Included)

Use new batteries to obtain best performance. Alkaline batteries recommended. Do not use rechargeable batteries. Non-rechargeable batteries are not to be recharged. Different types of batteries or new and used batteries are not to be mixed. Only batteries of the same or equivalent type as recommended are to be used. Batteries should be replaced by an adult. Batteries are to be inserted with the correct polarity. Exhausted batteries are to be removed from product. The supply terminals are not to be short-circuited. Batteries are to be removed from the product when not in use. Do not dispose of batteries in fire.



Figure 1: slot for coins



Not suitable for children under three years.

Start by placing the Vault on the table along with all the 18 game cards with their numbers facing upwards. Then, you must insert all the coins into the backside slot of the Vault (see figure 1). Make sure that you have securely closed the back panel of the Vault. Finally, you can switch on the Vault using the on/off switch on the bottom. Once the red light on the door starts blinking, you are ready to play!!

The Coins

The Vault randomly gives out 1, 2 or 3 coins each time it opens. There are three different types of coins.

1. Normal golden coin: Collect five of these and you win the game!
2. Diamond coin: These are more rare. You will only need two Diamond coins to win the game!
3. Alarm clock coin: If you find an alarm bell, it means that the police have been alerted! Immediately put all your coins back into the top of the vault (Figure 1), excluding the alarm coin.

